Brand	Device Name	Model Number	OS	Compatible
Google	Pixel 3	-	12.0	yes
Google	Pixel 3 XL	-	10.0	yes
Google	Pixel 3a	-	12.0	yes
Google	Pixel 4	-	12.0	yes
Google	Pixel 4a	-	12.0	yes
Google	Pixel 5	-	13.0	yes
Google	Pixel 5a	-	11.0	yes
Google	Pixel 6	-	13.0	yes
Google	Pixel 6a	-	13.0	yes
Google	Pixel 7	-	13.0	yes
Google	Pixel 7a	-	13.0	yes
Samsung	Galaxy S9	SM-G960U1	10.0	yes
Samsung	Galaxy S9 Plus	SM-G965U1	10.0	yes
Samsung	Galaxy S10	SM-G9730	12.0	yes
Samsung	Galaxy S10e	SM-G970F	11.0	yes
Samsung	Galaxy S20	SM-G9810	12.0	yes
Samsung	Galaxy S21	SM-G9910	12.0	yes
Samsung	Galaxy S21 Ultra	SM-G9980	12.0	yes
Samsung	Galaxy S22	SM-S9010	13.0	yes**
Samsung	Galaxy S23 Ultra	SM-S918N	13.0	yes**
Samsung	Galaxy Tab S4	SM-T830	10.0	yes
Samsung	Galaxy Tab S5e	SM-T720	11.0	yes
Samsung	Galaxy Tab S6	SM-T860N	12.0	yes
Samsung	Galaxy Tab S6 Lite	SM-P615N	12.0	yes
Samsung	Galaxy Tab S7	SM-T870	12.0	yes
Samsung	Galaxy Tab S7 FE	SM-T735N	11.0	yes
Samsung	Galaxy Tab S8	SM-X700	12.0	yes

<sup>\*</sup>Device compatibility may vary depending on the region or service provider

<sup>\*</sup>Some of the device listed above might not be sold in some countries.

<sup>\*</sup>The specification of the Android devices listed above is subject to change for certain reasons of manufacturer Please note that they may not operate properly with Smart Pianist depending on the changes. For detailed specification and information on the Android devices listed above, please contact the manufacture

<sup>\*</sup>The contents listed are the results of operational checks performed by Yamaha, and do not constitute a guar Yamaha assumes no responsibility for injuries occurring as a result of using this product.

<sup>\*\*</sup>Bluetooth MIDI connection is not established as of June 2023. Please wait for Android 13 QPR2 release.