



Sound Bar

Sound Bar 家庭劇院

# SR-B30A

Quick Guide..... 3

快速指南 ..... 11

EN

ZH-TW



Thank you for purchasing this Yamaha product.

This product is a bar-shaped speaker system that can be used by connecting it to a TV. Audio content from a Bluetooth® device can also be played through this product.

- Be sure to read this document and the included Safety Guide to ensure proper and safe use. Keep these documents readily available for future reference.

### Safety Guide

Be sure to read the Safety Guide first to ensure safe use.



### Quick Guide (this document)

This document describes the procedure for enjoying the sound of a TV.

- 1** Confirming contents of product package (p. 4)
  - 2** Preparing the remote control (p. 5)
  - 3** Installing the product (p. 5)
  - 4** Connecting to a TV (p. 6)
  - 5** Connecting to power (p. 7)
  - 6** Playing TV sound through the sound bar (p. 7)
- Adjusting the sound to your preference (p. 9)  
Listening to audio from a Bluetooth® device (p. 10)  
Controlling the sound bar with the smartphone app (p. 10)



### User Guide

More detailed information is described.

<https://manual.yamaha.com/av/23/srb30a/>



# 1 Confirming contents of product package

This product includes the following main devices and accessories. Take out all items from the box and make sure that all items are present.

## ■ Main device



Sound bar (SR-B30A)

## ■ Accessories



Remote control



Power cord



HDMI cable

- Quick Guide (this document)
- Safety Guide

Use when mounting the sound bar on a wall.




Spacers (x2)



Mounting template


## 2 Preparing the remote control

A Lithium battery (CR2025) has already been inserted into the remote control. Pull out the insulation sheet as follows so as to use the remote control.




### Operating range of the remote control

The remote control can be used to control the functions of this product. When using the remote control, point the remote control at the remote control sensor of the sound bar within the range shown in the following illustration:



## 3 Installing the product

Install the sound bar as shown in the following illustration.



For proper installation of the sound bar on a wall, make sure to have the work done by a contractor with qualified service personnel. See the Wall Mounting Installation Guide on our website for the installation method.




Wall Mounting  
Installation Guide

# 4

## Connecting to a TV

### Connect to a TV using the HDMI cable (included)

Connect to an HDMI input jack compatible with Audio Return Channel (labeled as “eARC” or “ARC”) on the TV using the included HDMI cable.




#### ■ NOTE


- Be sure to use the included HDMI cable.
- When connecting to a TV not compatible with ARC or connecting to an audio device, follow the connection procedure described in the User Guide.

## 5 Connecting to power

After connecting the sound bar to the TV, connect the sound bar to power as follows:



## 6 Playing TV sound through the sound bar



### 1 Turn on the TV.

When the the HDMI Control function of the TV is enabled (p. 8), the sound bar will also turn on. In this case, go to Step 4.

### 2 Turn on the sound bar.

Press the power button on the remote control.

### 3 Press TV.

### 4 Press VOLUME (+/-) to adjust the volume.

## HDMI Control function



When the sound bar is connected to the HDMI input jack compatible with Audio Return Channel (labeled as “eARC” or “ARC”) on a TV via an HDMI cable, control signals are transmitted from the TV to the sound bar.

This will enable you to use the HDMI Control function to control the sound bar using the TV's remote control. Also, the TV audio signal is transmitted to the sound bar via the HDMI cable.


Therefore, the sound bar can be connected to a TV using a single HDMI cable.

### ■ NOTE

- When the sound bar is connected to a TV via HDMI cable, confirm that the TV's settings are properly configured as follows:
  - The TV's HDMI Control function is enabled.
  - The audio output is not set to the TV speakers.
- Connect AV devices, such as BD/DVD players and set top boxes, to the TV's HDMI input jacks.



# Adjusting the sound to your preference



Remote control

## ① Listening to audio with sound that matches the video or music content (Sound mode)

A sound mode can be selected from among three sound modes that produce surround-sound fields and one sound mode for stereo playback. This function is STANDARD by default.

### STEREO

This sound mode provides stereo playback. This sound mode is best suited for music playback.

### STANDARD

This sound mode provides surround playback that is best suited for TV programs such as sports broadcasts. It emphasizes human voices and makes them easier to hear, while creating a sense of presence.

### MOVIE

This sound mode provides surround playback that is best suited for movies. It creates a sound space that seems to envelop your body.


## GAME

This sound mode provides surround playback that is best suited for video games. Accurate localization of individual sound effects provides a highly immersive gaming experience.

## ② Playing back human voices clearly (CLEAR VOICE)

The human voices within the audio can be heard more easily when the Clear Voice function is enabled. The function is recommended for playback at a low volume and for movies or dramas that use a lot of background music and sound effects.


Press CLEAR VOICE to enable or disable this function.



## ③ Enjoying rich bass sound (BASS EXT)

The bass sound is enhanced and becomes richer when the Bass Extension function is enabled.

Press BASS EXT to enable or disable this function.



## Listening to audio from a Bluetooth® device

Audio content from a Bluetooth device (such as a smartphone) can be played through the sound bar.



Bluetooth device

**1 Press BLUETOOTH on the remote control to switch the input source to Bluetooth.**

**2 On the Bluetooth device, enable the Bluetooth function.**

A list of Bluetooth devices that can be connected is displayed on the screen of the Bluetooth device.

**3 Select “Yamaha SR-B30A” or “SR-B30A” within the list.**

**4 Play a song on the Bluetooth device when the connection is established.**

The sound bar will begin playing audio from the Bluetooth device.

### ■ NOTE

This product can be connected to two Bluetooth devices simultaneously (multipoint connection). To switch between two Bluetooth devices to be played, stop playback on the currently playing device and then start playback on the other.

## Controlling the sound bar with the smartphone app



By installing the free dedicated app “**Sound Bar Remote**” on a smartphone, the sound bar can also be controlled from that smartphone. The app allows you to control the sound bar while checking the sound bar settings currently applied, such as sound mode and volume adjustment of each frequency range (tone control), via the app’s screen.

Search for “**Sound Bar Remote**” on the App Store or Google Play and install it on the smartphone.

For details on the app, see the description of the app on the App Store or Google Play.

### ■ NOTE

- To control the sound bar using the app, configure the settings on your smartphone as follows:
  - Enable the Bluetooth function.
  - For devices using the Android 11 OS or earlier, configure the settings to allow location information to be obtained.

The Sound Bar Remote app uses location information from the Android device only to detect the sound bar. The acquired location information will not be used for any other purpose.
  - For devices using the Android 12 OS or later, configure the settings to allow the use of nearby devices.
- This sound bar is only compatible with the Sound Bar Remote app. The sound bar cannot be controlled using other apps (such as Sound Bar Controller).

感謝您購買本 Yamaha 產品。

本產品為條形揚聲器系統，可透過將其連接到電視來使用。來自 Bluetooth® 裝置的音訊內容亦可透過本產品播放。

請務必閱讀本文件和隨附的「安全指南」以確保正確且安全的使用。請妥善保管這些文件以備日後參考。

## 安全指南

請務必先閱讀 安全指南 以確保安全的使用。



## 快速指南 (本文件)

本文件說明享受電視聲音的程序。

- 1 確認產品包裝的內容 (p. 12)
  - 2 準備遙控器 (p. 13)
  - 3 安裝本產品 (p. 13)
  - 4 連接到電視 (p. 14)
  - 5 連接到電源 (p. 15)
  - 6 透過條形音箱播放電視聲音 (p. 15)
- 根據您的喜好調整聲音 (p. 17)  
收聽來自 Bluetooth® 裝置的音訊 (p. 18)  
使用智慧型手機應用程式控制條形音箱 (p. 18)



## 使用指南

說明更詳細的資訊。

<https://manual.yamaha.com/av/23/srb30a/>



# 1

## 確認產品包裝的內容

本產品包含以下主要裝置和配件。從盒子中取出所有物品並確保所有物品都存在。

### ■ 主要裝置



條形音箱 (SR-B30A)

### ■ 配件



遙控器



電源線



HDMI 纜線

- 快速指南 (本文件)
- 安全指南

將條形音箱安裝在牆上時使用。




墊片 (x2)



安裝模板


## 2 準備遙控器

遙控器裡已裝有一個鋰電池（CR2025）。如下拉出絕緣片以使用遙控器。




### 遙控器操作範圍

遙控器可用於控制本產品的功能。使用遙控器時，請在下圖所示的範圍內將遙控器對準條形音箱的遙控器傳感器：



## 3 安裝本產品

如下圖所示安裝條形音箱。



為了在牆上正確安裝條形音箱，請確保由具有合格服務人員的承包商執行作業。有關安裝方法，請參閱本公司網站上的 壁掛式安裝指南。




壁掛式安裝指南

## 4

## 連接到電視

## 使用 HDMI 纜線（隨附）連接到電視

使用隨附的 HDMI 纜線連接到電視上與 Audio Return Channel（標記為「eARC」或「ARC」）相容的 HDMI 輸入插孔。




## ■ 註

- 務必使用隨附的 HDMI 纜線。
- 當連接到與 ARC 不相容的電視或連接到音訊裝置時，請按照 使用指南中描述的連接程序進行操作。


## 5 連接到電源

將條形音箱連接到電視後，請將條形音箱連接到電源，如下所示：

條形音箱（背面）



## 6 透過條形音箱播放電視聲音



- 1 開啟電視。  
當電視的 HDMI 控制功能啟用時 ( p. 16 )，條形音箱也將開啟。在這種情況下，請前往步驟 4。
- 2 開啟條形音箱。  
按遙控器上的電源按鈕。
- 3 按 TV。
- 4 按 VOLUME (+/-) 調整音量。

## HDMI 控制功能




當條形音箱透過 HDMI 纜線連接到電視上與 Audio Return Channel（標記為「eARC」或「ARC」）相容的 HDMI 輸入插孔時，控制訊號會從電視傳輸到條形音箱。這將使您能夠使用 HDMI 控制功能，用電視遙控器來控制條形音箱。此外，電視音訊訊號經由 HDMI 纜線傳輸到條形音箱。因此，可以使用單條 HDMI 纜線將條形音箱連接到電視。

### ■ 註

- 當條形音箱透過 HDMI 纜線連接到電視時，請確認電視的設定正確配置如下：
  - 電視的 HDMI 控制功能已啟用。
  - 音訊輸出未設定為電視揚聲器。
- 將 AV 裝置（例如 BD/DVD 播放器和機頂盒）連接到電視的 HDMI 輸入插孔。



# 根據您的喜好調整聲音



## ① 聆聽聲音與視訊或音樂內容相配的音訊(聲音模式)

可以從產生環繞音場的三種聲音模式和一種用於立體聲播放的聲音模式中選擇一種聲音模式。此功能的原廠設定為 STANDARD。

### STEREO

此聲音模式提供立體聲播放。此聲音模式最適合音樂播放。

### STANDARD

此聲音模式提供最適合體育轉播等電視節目的環繞聲播放。其強調人聲，讓人的聲音更容易聽見，同時創造臨場感。

### MOVIE

此聲音模式提供最適合電影的環繞聲播放。其創造一個似乎將您的身體圍繞的聲音空間。


### GAME

此聲音模式提供最適合視訊遊戲的環繞聲播放。個別音效的準確定位提供高度身臨其境的遊戲體驗。

## ② 清晰地播放人聲 (CLEAR VOICE)

啟用清晰語音功能時，可以更容易地聽到音訊中的人聲。對於以低音量播放以及使用大量背景音樂和音效的電影或戲劇，建議使用此功能。

按 CLEAR VOICE 啟用或停用此功能。



## ③ 享受豐沛的低音音效 (BASS EXT)

啟用低音延伸功能時，低音會增強並變得更豐沛。

按 BASS EXT 啟用或停用此功能。



## 收聽來自 Bluetooth® 裝置的音訊

來自 Bluetooth 裝置的音訊內容（例如智慧型手機）可透過條形音箱播放。



Bluetooth 裝置

- 1 按遙控器上的 **BLUETOOTH** 將輸入源切換為 **Bluetooth**。
- 2 在 **Bluetooth** 裝置上，啟用 **Bluetooth** 功能。  
可連接的 Bluetooth 裝置列表會顯示在 Bluetooth 裝置的螢幕上。
- 3 在列表中選擇「**Yamaha SR-B30A**」或「**SR-B30A**」。
- 4 建立連接後在 **Bluetooth** 裝置上播放歌曲。  
條形音箱將開始播放來自 Bluetooth 裝置的音訊。

### ■ 註

本產品可以同時連接到兩台 Bluetooth 裝置（多點連接）。若要在兩台欲播放的 Bluetooth 裝置之間切換，請先在當前播放中的裝置上停止播放，然後在另一台裝置上開始播放。

## 使用智慧型手機應用程式控制條形音箱



透過在智慧型手機上安裝免費的專用應用程式「**Sound Bar Remote**」，也可從該智慧型手機控制條形音箱。該應用程式可讓您在透過應用程式的螢幕檢查目前套用的條形音箱設定（例如聲音模式以及各頻率範圍的音量調整（音調控制））的同時控制條形音箱。

在 App Store 或 Google Play 搜尋「**Sound Bar Remote**」，並將其安裝在智慧型手機。

有關應用程式的詳情，請參閱 App Store 或 Google Play 上的應用程式說明。

### ■ 註

- 若要使用應用程式來控制條形音箱，請在您的智慧型手機上如下配置設定：
  - 啟用 **Bluetooth** 功能。
  - 對於使用 **Android 11 OS** 或更舊版本的裝置，請配置設定以允許取得位置資訊。  
**Sound Bar Remote** 應用程式僅將 **Android** 裝置中的位置資訊用於檢測條形音箱。取得的位置資訊不會用於任何其他目的。
  - 對於使用 **Android 12 OS** 或更新版本的裝置，請配置設定以允許使用附近的裝置。
- 此條形音箱僅與 **Sound Bar Remote** 應用程式相容。無法使用其他應用程式（例如 **Sound Bar Controller**）來控制條形音箱。



YAMAHA CORPORATION

10-1 Nakazawa-cho, Naka-ku, Hamamatsu, 430-8650 Japan

Yamaha Global Site  
<https://www.yamaha.com/>

Yamaha Downloads  
<https://download.yamaha.com/>

© 2023 Yamaha Corporation  
Published 06/2023  
KSOD-A0

VGM6570

V